



Installation Instructions for Skyliner™ Brace Cover

Skyliner Brace Cover is installed after the incision made to reattach the flange brace cover has been properly closed (to prevent moisture infiltration) with tapes and adhesive (provided).

Make a minimum "L" shape slice in the Brace Cover fabric, and slide over the flange brace cover and up to the fabric liner.

Once the Brace Cover is in place and securely adhered to fabric liner, install two tech 2 screws through the Brace Cover, fabric and into the purlin.

Skyliner Brace Cover is cosmetic and not a vapor retarder.

**Questions? Contact your Bay District
Manager, call 844.999.7153 or visit
www.SkylinerSystems.com.**

(Actual fabric)

