



## Sag N Bag System

### Set-Up and Operation

- First layer of faced insulation is installed perpendicular to and over the purlins, with the overall extra length to sag down evenly in between the purlins.
- Top layer is installed parallel to and between the purlins on top of the “sagged” faced insulation.

### Considerations

- **Insulation:** between/over purlins, no banding
- **Appearance:** purlins exposed
- **Building type:** steeper pitches ok
- **Application:** new
- Meets older codes (IECC 2009, ASHRAE 2010)

**Questions? Contact your Bay District Manager.**

