



SkyLiner® Fabric Repair Tape

Skyliner® Fabric Repair Tape is for use to repair small cuts or punctures in the fabric to maintain the integrity of the vapor retarder and retain the cosmetic finish of the application.

Great care should be made during and after installation to not cut or tear the Skyliner fabric. When repair tape is used, it is recommended to use the smallest piece possible to cover the cut or puncture.

Product Description		Tape Specifications	
Repair tape made of Skyliner Fabric with aggressive, quick stick, synthetic rubber-based adhesive for bonding applications.		Weave	Woven HDPE scrim
		Fabric Thickness	9.0 mil nominal
		Adhesive Thickness	3.0 mils +/- 10%
		Total Thickness	12.0 mils nominal
		Color	White / blue
		Peel Adhesion @ 1 mil/inch of width	5.5 lbs.
Roll Size			
Width	3 in.		
Length	100 ft.		

Questions? Contact your Bay District Manager, call **844.999.7153** or visit www.SkylinerSystems.com.

